



1	PC6 RESET#	PC0 ADC0	23
2	PD0 RXD	PC1 ADC1	24
3	PD1 TXD	PC2 ADC2	25
9	PB6 XTAL1	PC3 ADC3	26
10	PB7 XTAL2	PC4 ADC4	27
		PC5 ADC5	28
4	INT0 PD2		
5	INT1 PD3		
6	T0 PD4		
11	T1 PD5		
12	AIN0 PD6		
13	AIN1 PD7		
14	PCINT0 PB0		
15	PCINT1 PB1		
16	PCINT2 PB2		
17	PCINT3 PB3		
18	PCINT4 PB4		
19	PCINT5 PB5		

U4 ATMEGA328P-PU