



MEGA8-P

1	PC6/(RESET)	23	PC0(ADC0)
2	GND	24	PC1(ADC1)
3	22	25	PC2(ADC2)
4	21	26	PC3(ADC3)
5	20	27	PC4(ADC4/SDA)
6	9	28	PC5(ADC5/SCL)
7	10		
8	8		
9	7		
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			

